

# Автомобильные тормозные стенды BD 4481



Архангельск (8182)63-90-72  
Астана (7172)727-132  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16

Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://beissbarth.nt-rt.ru> || [bhp@nt-rt.ru](mailto:bhp@nt-rt.ru)

## Car brake tester BD 4481

Maximum test weight/axle 4.0 t, Test Speed 5.2 km/h, Speed sensors | without Analog display, flexible solution via customer PC (PC Kit is needed) | elektromagnetic brake, 4x4, Roller width 1000 mm | Extension possibility to test lanes | New! Power-Box inclusive!

Article number: 1 691 600 868



### New! Power Box for the BD car series

- BD car brake testers comply with the guideline and are thus suitable for general vehicle inspections. At the same time, there are modular auxiliaries for diagnoses as well as repair and service tasks at the workshop. Absolutely in line with specific customer requirements, the brake tester can be expanded and turned into a test lane for suspension testing and side slip testing. Operation, visualization and evaluation of the test results are made by means of an analogue display or via PC.

### Just use the workshop computer

- The new kits allow additional connectivity options for the BD series. The integrated PC kit is designed for its installation inside the new Power Box and allows direct linkage to the workshop PC.

### More service, more customers

In order to ease and speed up the brake service, the BD car series and the new Bosch Power Box can be complemented by powerful accessories:

- Column for the Power Box
- PC trolley
- LCD display set for the display unit
- Professional IR PC kits (integrated or external)
- Pedal-force sensor (wireless version)
- Roller covers
- IR remote control

### Access to multiple functions by means of a linked workshop PC

- Visualization of test procedures and results via screen
- Job processing, customer database, statistic evaluation or print and archiving functions can be used to full extent
- Test protocols are printed automatically
- Quick extension and conversion into a test lane is possible
- Analogue display is not required

### Power Box for the BD car series

- Compact, robust and service-friendly
- All electronics are compact and safety stowed
- Easily accessible on the wall or on column
- All electronic components are safely stored within a light-weight and easily accessible housing
- 230 V socket for the laptop of the service-technician or tester
- Easily accessible main switch with emergency shutdown
- Integrated door pocket for the technical documentation
- Wall mount (series version) or column (optional)

### Four possibilities for PC connections

To operate with PC, one of the following kits is needed

- Integrated ICperform PC-Kit (incl. ICperform Software license and Tablet app license), part No. 1 691 601 964
- External ICperform PC-Kit (incl. ICperform Software license and Tablet app license), part No. 1 691 601 965
- Integrated ICperform PC-Kit with Remote Control (incl. ICperform Software license), part No. 1 691 601 963
- External ICperform PC-Kit with Remote Control (incl. ICperform Software license), part No. 1 691 601 966

## Car brake tester BD 4481 S20

Maximum test weight/axle 4.0 t, Test Speed 5.2 km/h, Speed sensors | without Analog display, flexible solution via customer PC (PC Kit is needed) | elektromagnetic brake, 4x4, Roller width 1000 mm | Extension possibility to test lanes | New! Power-Box inclusive! | Spike Rollers

Article number: 1 691 600 682



### New! Power Box for the BD car series

- BD car brake testers comply with the guideline and are thus suitable for general vehicle inspections. At the same time, there are modular auxiliaries for diagnoses as well as repair and service tasks at the workshop. Absolutely in line with specific customer requirements, the brake tester can be expanded and turned into a test lane for suspension testing and side slip testing. Operation, visualization and evaluation of the test results are made by means of an analogue display or via PC.

### Just use the workshop computer

- The new kits allow additional connectivity options for the BD series. The integrated PC kit is designed for its installation inside the new Power Box and allows direct linkage to the workshop PC.

### More service, more customers

In order to ease and speed up the brake service, the BD car series and the new Bosch Power Box can be complemented by powerful accessories:

- Column for the Power Box
- PC trolley
- LCD display set for the display unit
- Professional IR PC kits (integrated or external)
- Pedal-force sensor (wireless version)
- Roller covers
- IR remote control

### Access to multiple functions by means of a linked workshop PC

- Visualization of test procedures and results via screen
- Job processing, customer database, statistic evaluation or print and archiving functions can be used to full extent
- Test protocols are printed automatically
- Quick extension and conversion into a test lane is possible
- Analogue display is not required

### Power Box for the BD car series

- Compact, robust and service-friendly
- All electronics are compact and safety stowed
- Easily accessible on the wall or on column
- All electronic components are safely stored within a light-weight and easily accessible housing
- 230 V socket for the laptop of the service-technician or tester
- Easily accessible main switch with emergency shutdown
- Integrated door pocket for the technical documentation
- Wall mount (series version) or column (optional)

### Four possibilities for PC connections

To operate with PC, one of the following kits is needed

- Integrated ICperform PC-Kit (incl. ICperform Software license and Tablet app license), part No. 1 691 601 964
- External ICperform PC-Kit (incl. ICperform Software license and Tablet app license), part No. 1 691 601 965
- Integrated ICperform PC-Kit with Remote Control (incl. ICperform Software license), part No. 1 691 601 963
- External ICperform PC-Kit with Remote Control (incl. ICperform Software license), part No. 1 691 601 966



**Архангельск** (8182)63-90-72  
**Астана** (7172)727-132  
**Астрахань** (8512)99-46-04  
**Барнаул** (3852)73-04-60  
**Белгород** (4722)40-23-64  
**Брянск** (4832)59-03-52  
**Владивосток** (423)249-28-31  
**Волгоград** (844)278-03-48  
**Вологда** (8172)26-41-59  
**Воронеж** (473)204-51-73  
**Екатеринбург** (343)384-55-89  
**Иваново** (4932)77-34-06

**Ижевск** (3412)26-03-58  
**Иркутск** (395)279-98-46  
**Казань** (843)206-01-48  
**Калининград** (4012)72-03-81  
**Калуга** (4842)92-23-67  
**Кемерово** (3842)65-04-62  
**Киров** (8332)68-02-04  
**Краснодар** (861)203-40-90  
**Красноярск** (391)204-63-61  
**Курск** (4712)77-13-04  
**Липецк** (4742)52-20-81

**Магнитогорск** (3519)55-03-13  
**Москва** (495)268-04-70  
**Мурманск** (8152)59-64-93  
**Набережные Челны** (8552)20-53-41  
**Нижний Новгород** (831)429-08-12  
**Новокузнецк** (3843)20-46-81  
**Новосибирск** (383)227-86-73  
**Омск** (3812)21-46-40  
**Орел** (4862)44-53-42  
**Оренбург** (3532)37-68-04  
**Пенза** (8412)22-31-16

**Пермь** (342)205-81-47  
**Ростов-на-Дону** (863)308-18-15  
**Рязань** (4912)46-61-64  
**Самара** (846)206-03-16  
**Санкт-Петербург** (812)309-46-40  
**Саратов** (845)249-38-78  
**Севастополь** (8692)22-31-93  
**Симферополь** (3652)67-13-56  
**Смоленск** (4812)29-41-54  
**Сочи** (862)225-72-31  
**Ставрополь** (8652)20-65-13

**Сургут** (3462)77-98-35  
**Тверь** (4822)63-31-35  
**Томск** (3822)98-41-53  
**Тула** (4872)74-02-29  
**Тюмень** (3452)66-21-18  
**Ульяновск** (8422)24-23-59  
**Уфа** (347)229-48-12  
**Хабаровск** (4212)92-98-04  
**Челябинск** (351)202-03-61  
**Череповец** (8202)49-02-64  
**Ярославль** (4852)69-52-93

**Киргизия** (996)312-96-26-47

**Россия** (495)268-04-70

**Казахстан** (772)734-952-31

<https://beissbarth.nt-rt.ru> || [bhp@nt-rt.ru](mailto:bhp@nt-rt.ru)